

# ROMIK

## Installation Instructions

Part No. **2137**

Product: Romik "Connect" Running Boards

Application: **Ford Transit 2014 – Present**

Level of Difficulty: 1 2 **3** 4 5

Installation Time: 120 Min.


REV 7 02/01/23

Hardware	Torque Aluminum	Torque Steel to Steel
M6 Bolt	3 ft-lbs.	14 ft-lbs.
M8 Bolt	7 ft-lbs.	35 ft-lbs.
M10 Bolt	16 ft-lbs.	64 ft-lbs.
M12 Bolt	28 ft-lbs.	112 ft-lbs.

**ATTENTION:** Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty. If you have any questions, please contact our technical team at 1-866-717-6645

Attention: Please make sure that you have the latest instructions from *Romik.com*

QR Scan



1



DRIVER SIDE  
FRONT BRACKET-1  
1 x QTY

2



DRIVER SIDE  
FRONT BRACKET-2  
1 x QTY

3



DRIVER SIDE  
FRONT BRACKET-4  
1 x QTY

4



DRIVER SIDE  
FRONT BRACKET-3  
1 x QTY

5



PASSENGER SIDE  
FRONT BRACKET-1  
1 x QTY

6



PASSENGER SIDE  
FRONT BRACKET-2  
1 x QTY

21



PASSENGER SIDE  
FRONT BRACKET-3  
1 x QTY

22



PASSENGER SIDE  
FRONT BRACKET-4  
1 x QTY

20



PASSENGER SIDE  
CENTER BRACKET-1  
2 x QTY

7



PASSENGER SIDE  
REAR BRACKET-1  
1 x QTY

8



PASSENGER SIDE  
REAR BRACKET-2  
1 x QTY

14



PASSENGER SIDE  
REAR BRACKET-3  
[WITH A/C]  
1 x QTY

## HARDWARE

11



HTC 226 - M8x30  
1x

9



HTC 243 - M10x25  
6x

13



HTC 262 - M10x30  
1x

10



HTC 269 - CLIPS (M10)  
9x

12



HTC 271 - CLIPS (M8)  
1x

15



M10x25 FLANGE BOLT  
8x

16



M8x25 FLANGE BOLT  
2x

17



M10 FLANGE NUT  
14x

18



M8 FLANGE NUT  
5x

19



M8 WASHER  
4x

# Installation Instructions 2137 Bracket Kit


Video  
Installation  
Instruction:




**Step 1:** Locate mounting locations and hardware as per 1<sup>st</sup> page of this installation manual

**Important Install Tip:** When installing Romik HTC inserts, place black plastic washer on the treaded part. On **Vertical installations** the HTC must be seated at the **12 o'clock position**. On Horizontal installations make sure to push the HTC insert to the opposite position to catch the lip. **NOTE HTC must NEVER be centered**. Test by tugging on it before installing bracket.


To avoid insert from rotating put pressure on the bracket while tightening the insert by hand. Do not use power tools as this will spin the insert and potentially damage it.



**Step 2:** Pre-assemble front drivers bracket #1 and #2 for easy installation. If equipped with mudflaps remove screw holding mudflap bracket as shown on Figure 1. This will be reused. If the vehicle does not have mudflaps proceed from Figure 2. Install provided HTC 243 and M10 bolt as shown Figure 3. Install pre-assembled bracket as shown on Figure 4



**Step 3:** Pre-assemble rear drivers brackets #4 and #3, Install provided HTC 243 as shown Figure 5






# Installation Instructions 2137 Bracket Kit

**Step 4:** If vehicle is equipped with rear ac. Remove factory screw (will be re-used) Figure 6. If vehicle does not have rear ac proceed to install HTC 226 Figure 7. Proceed to install pre-assembled bracket as shown

Figure 8. Do not tighten.



**Step 5:** Pre-assemble passenger side front brackets #5 and #6. Locate mounting points and install provided HTC 243 and M10 bolt If equipped with mudflaps please review step 2 Figure 9.



**Step 6:** Install pre-assembled bracket do not tighten



**Step 7:** Pre-assemble passenger side front brackets #21 and #22. Locate mounting points and install provided HTC 243 Figure 11.




# Installation Instructions 2137 Bracket Kit



**Step 8:** Install pre-assembled brackets as shown on Figure 12. Do not tighten



**Step 9:** Middle brackets #20 do not require pre-assembly clean factory threads Figure 13 and install using supplied M8 hardware. **Note some models do not have threaded inserts on bottom mount and may require tapping to M8 25** proceed to install. Do not tighten




**Step 10:** Note: If your vehicle is a short wheel base please skip to Step 11. Pre-assemble bracket #7 and #8 and install provided HTC 243 as show Figure 14. Install pre-assembled bracket Figure 15. Do not tighten




# Installation Instructions 2137 Bracket Kit

**Step 11:** This step is for short wheel base models only, if you have completed step 8 please proceed to step 10, install provided HTC 243 and attach bracket Figure 14. Do not tighten



NOTE: Romik connect is a two piece running board. Make sure to use the supplied aluminum connectors as shown on the next pages



**Step 10:** Proceed to last page of this manual for running board install instructions and torque values

For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.


***Thank you for choosing Romik.***




# ROF / ROB / RPD 2 PC Romik Connect instructions

Please follow these steps to successfully “join” the 2 PC running boards together.


**Step 1:** Remove products from box and placed on a soft surface to avoid scratching.



**Step 2:** Remove plastic endcap as shown on Figure A1 – A4 keep screws as they will be re-used.



**Step 3:** Remove Romik Connect plate and assemble as show on Figure B1 – B3 using original screws. Join two running boards together using supplied M8 bolts torque to 7 ft lbs.



**Step 4:** Install running boards as per last page of this manual.

# Installation Instructions Running Boards

**NOTE: Use of power tools will damage the bottom of the running board and void your warranty.**

**Step 1: loosen the M8 hardware on back of the running boards.**

**Step 2: Slide running board onto brackets**

**Step 3: Tighten hardware to 7 ft lbs.**



## ROF/RPD/ROB Running boards

**Step 1: Place clamping plate on top of running board as shown below. Make sure clamping plate sits correctly on running board surface.**

**Step 2: Install carriage bolts and plastic retaining clips as shown below.**

**Step 3: Install and tighten hardware to 7 ft lbs.**



## Product Registration and Warranty Information

- Register your Romik products at <https://romik.com/productregistration>
- Warranty information at <http://www.romik.com/warranty>

## Cleaning and maintaining your Romik Running boards

Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.

For video instructions on how to clean your Romik products please click here <https://romik.com/cleaning>