



Installation Instructions

Part No. **1440**

Product: Running Boards

Application:

Chevy Equinox / GMC Terrain 2025-Present

Level of Difficulty: 1 2 **3** 4 5

Professional Installation Time: 90 Min.

DIY Installation Time: 180 Min


REV 1 01/01/26

Hardware	Torque Aluminum	Torque Steel to Steel
M6 Bolt	3 ft-lbs.	14 ft-lbs.
M8 Bolt	7 ft-lbs.	35 ft-lbs.
M10 Bolt	16 ft-lbs.	64 ft-lbs.
M12 Bolt	28 ft-lbs.	112 ft-lbs.













ATTENTION: Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty. If you have any questions, please contact our technical team at 1-866-717-6645

Attention: Please make sure that you have the latest instructions from **Romik.com**





QR Scan



1440


 1	 2	 3	 4
 5	 6	 7	 8
 9	 10	 11	 12
DRIVER SIDE FRONT BRACKET-1 1 x QTY	DRIVER SIDE FRONT BRACKET-2 1 x QTY	DRIVER SIDE CENTER BRACKET-1 1 x QTY	DRIVER SIDE CENTER BRACKET-2 1 x QTY
DRIVER SIDE REAR BRACKET-1 1 x QTY	DRIVER SIDE REAR BRACKET-2 1 x QTY	PASSENGER SIDE FRONT BRACKET-1 1 x QTY	PASSENGER SIDE FRONT BRACKET-2 1 x QTY
PASSENGER SIDE CENTER BRACKET-1 1 x QTY	PASSENGER SIDE CENTER BRACKET-2 1 x QTY	PASSENGER SIDE REAR BRACKET-1 1 x QTY	PASSENGER SIDE REAR BRACKET-2 1 x QTY

HARDWARE

 13	 14	 15	 16
HTC 243 – M10x25 (4x12x50) 4x	HTC 262 – M10x30 (5x15x60) 2x	HTC 311 – M8 (21.3x11.75) 2x	HTC 326 – M10x40 (5x34x60) 2x
 17	 18	 19	 20
HTC 269 M10 CLIPS 8x	HTC 271 M8 CLIPS 2x	HTC 314 2x	M8 – HEX FLANGE NUT 8x
 21	 22	 23	 24
M10 – HEX FLANGE NUT 8x	M8 – WASHER 2x	M8x25 – HEX FLANGE BOLT 8x	M8x40 – FLANGE BOLT HOLES 2x

Installation Instructions 1440 Bracket Kit

Important Install Tip: When installing Romik HTC inserts follow the sequence below. Make sure the HTC is seated correctly and do not use power tools as this will only spin the insert and possibly damage it. Test by tugging on it before installing bracket. **Blue loctite is highly recommended on all metal parts.**




PROFESSIONAL INSTALLATION RECOMMENDED

Step 1: Pre-assemble brackets as per front page (driver's side shown below)




Step 2: Locate front bracket mounting location. Figure 1.



Installation Instructions 1440 Bracket Kit

Step 3: Install provided hardware #13 HTC 243 and #14 HTC 262 Figure 2.




Step 4: Install pre-assembled bracket as shown on Figure 3. Use provided M10 hardware. Do not tighten.



Installation Instructions 1440 Bracket Kit

Step 5: Locate middle bracket mounting area. Note use last crossmember (driver's side shown) Figure 4.




NOTE: Please use the appropriate way that you may want to perform this installation. The quickest way is Option #2 and use the included HTC 311.

Step 6: Option #1 using the supplied wire #24 M8-40 and #19 HTC 314 pass the wire through the chassis Figure 5, Figure 6 and Figure 7.




Installation Instructions 1440 Bracket Kit




Installation Instructions 1440 Bracket Kit

Option #2

Using a 1/2 inch drill bit enlarge the factory hole and insert #15 HTC 311 as show Figure 8.




Step 7: Install supplied #13 HTC 243, using supplied hardware install pre-assembled bracket as shown Figure 9. Do not tighten




Installation Instructions 1440 Bracket Kit

Step 8: Locate rear bracket mounting area. Figure 10.



Step 9: Install #16 HTC 326 and #15 HTC 311 with #23 M8x25 bolt as shown Figure 11.




Installation Instructions 1440 Bracket Kit

Step 10: Install pre-assembled rear bracket as shown Figure 12. Do not tighten.

Figure 12



Proceed to last page of this manual for running board install instructions and torque values



For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.

Thank you for choosing



Installation Instructions Running Boards

NOTE: Use of power tools will damage the bottom of the running board and void your warranty.

Step 1: loosen the M8 hardware on back of the running boards.

Step 2: Slide running board onto brackets

Step 3: Tighten hardware to 7 ft lbs.




ROF/RPD/ROB Running boards

Step 1: Place clamping plate on top of running board as shown below. Make sure clamping plate sits correctly on running board surface.

Step 2: Install carriage bolts and plastic retaining clips as shown below.

Step 3: Install and tighten hardware to 7 ft lbs.



Product Registration and Warranty Information

- Register your Romik products at <https://romik.com/productregistration>
- Warranty information at <http://www.romik.com/warranty>



Cleaning and maintaining your Romik Running boards

Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.

For video instructions on how to clean your Romik products please click here <https://romik.com/cleaning>